

# C15 ECO Rinse Aid

## Rinse Aid for crockery rinsing in the dishwasher

removes lime scale from dishes, leaving a perfect bright surface. Particularly suitable for soft water / osmotized water.

Ideal for ceramics, porcelain, glass and crystal. Perfect to support plastic objects drying.

### Area of application

Professional kitchens, cafeterias, bars, restaurants, canteens, commercial catering kitchens

**Suitable for:** hood type dishwashers, undercounter, glasswashers, pot and pan washers



### Description

**C15 ECO Rinse Aid for dishwashers** guarantees the perfect drying of crockery, dishes and glasses avoiding the manual drying. It removes the remaining limestones. It is indispensable in case of glasswashers.

**This product is the result of thorough testing in the Electrolux Professional laboratories. C15 ECO Rinse Aid for dishwashers** is the best solution for sparkling clean crockery, and for maintaining high performance levels of the dishwasher.



Scan the QR code to view the safety data sheet

## Recommendations

For optimal results, use the recommended dosage of **ECO Rinse Aid for dishwashers**. To obtain the highest levels of efficiency, it is important to periodically check the dishwasher's rinse water pressure and the temperature of the boiler.

## C15 ECO Rinse Aid for dishwashers

### Chemical-physical characteristics

Appearance	Clear liquid
Colour	Light blue
Odour	Slight characteristic
Relative density	0.98 g/ml
Water solubility	Complete in all ratio
pH	6.5 - 7



## Instructions for use

Water hardness				Dosage	
°f	°d	°e	ppm	Hardness	ml/L
0 - 7	0 - 3,9	0 - 4,9	0 - 70	soft	0,05 - 0.5

In cup washers using built-in dosage unit, it will be sufficient to dip the suction tube in the product's can; otherwise simply fill the specific basin, following the dishwasher instructions.

**Foaming power:** low

**Package and code:**

2 x 5L cans - code 0S2904

## Warnings:

- the product is for professional use only; do not use in domestic appliances.
- transport and storage must be done only in the original package, upright position.
- do not expose to sunlight and freezing temperatures.
- do not transfer in other bottles.
- do not mix with other products.
- to be used within 30 months after the production date.
- the package and containers are totally recyclable.
- please handle the emptied material according to the local recycling regulation.